PIRANHA OFFROAD PRODUCTS

BTLDS4

'Piranha Off Road products are not associated in any way with JAGUAR LAND ROVER Ltd or any of its related companies'

To Suit LAND ROVER DISCOVERY SERIES 4 TD V6













PARTS INCLUDED WITH TRAY

- 1 X Tray
- 2 X M6 Countersunk
- 1 X M6 Long
- 1 X M6 Washer
- 1 X Standard Top Mount
- 2 X J Bolts

FITTING INSTRUCTIONS

The cradle fits passenger side front

- 1. Remove looms from inner guard & one bolt in over flow bottle mount.
- 2. Place tray into position, re-directing looms under & around battery tray.
- 3. Align all holes. Place new bolts in, 2 x M6 C/Sunk in rear of tray & 1 x M6 Long
- & Washer in front leg.
- 4. Once all three bolts are in, they can now be tightened.
- 5. Place battery into position & bolt down using J Bolts & Hold Down.

RECOMMENDED ISOLATOR

DBE140SF or DBE180-SX

Ensure, Before closing the bonnet that all items fitted have adequate clearance

Nov 2017