

Outback Accessories Australia

Part No. RSGQS - X-ROX Side Protection

Nissan GQ - SWB

The X-ROX slider was developed to protect the sill and lower panels of the vehicle when serious off roading.

This slider is not intended to be, and cannot be used as, a step.

Fitting Instructions

1. Remove OE side steps if fitted.
2. Working from the L/H side fit the centre mount around the chassis, between chassis and brake pipes. Jack up the front of the bar into position around the chassis gusset of the chassis/body mount. Then jack the rear up to line up with the hole in the bottom of the radius arm mount on the chassis.
3. With the bar in position and parallel with the body, the two front holes can be drilled then the rear hole and the centre mount hole through the chassis.
4. Secure the front mount with 2) M12x30 bolt, f/washers, s/washers and M12 nuts. Centre mount with 1) M12x110 Bolt, 2) F/washers, 2) S/washers and 2) M12 nuts. Rear mount with 2) M12x30 bolts, 4) f/washers, 2) s/washers, 2) M12 nuts. Tighten all bolts.
5. Repeat instruction for the R/H side fit up.

Kit Contents

Qty.	Description	Qty.	Description
1	RSGQS Slider R/H	10	12mm Nuts
1	RSGQS Slider L/H	20	12x3mm thick Flat Washers
8	12x30mm Bolts	10	12mm Spring Washer
2	12 x 110mm Bolts	1	Fitting instruction

Kit Packed by:	Checked By:	Date:
----------------	-------------	-------