

# PACKAGE CONTAINS

## FOR GWM UTE CANNON

2 x cables

2 x rubbers

1 x easy up strut

1 x slow down strut



# INSTALLATION INSTRUCTIONS FOR GWM UTE CANNON

## 01

Remove the steel strap from the body by loosening the bolt (please keep the factory washer) and remove the rubber



## 02

Install the slow down strut. Place the cable on first, followed by the factory washer.

Ensure when tightening, the cable is sitting on the shoulder of the bolt and the cable remains free



## 03

Remove the factory bolt from the hinge closest to the tub (yellow arrow) and install the bottom of the strut as shown. Attach the cable to the factory bracket.

Clean the lip of the tailgate as shown and stick the rubber with the angle facing in. (This is to fix the motion path of cables so they don't get caught)



## 04

Now you have done the installation for slow down strut. Repeat the same process on the passenger side for the easy up strut.

Once the easy up strut is installed let the tailgate down and remove the plastic spacer from easy up strut.

