

FORD RANGER PX 2012-2021

PACKAGE CONTAINS



1 x easy up strut
(passenger side)

2 x rubbers

1 x slow down strut
(driver side)

INSTALLATION INSTRUCTIONS

FOR FORD RANGER PX 2012-2021

** Installation begins from the Driver Side **

01

Remove the bolt and cable from the body

Attach the cable into the slow down strut and install to marked area



02

Remove the bolt nearest the body

Place the bottom of the strut over the tailgate bracket and tighten the bolt
(Make sure that the lip of the bracket sits under the plate)



03

Repeat the same process in step 1&2 on the passenger side for the easy up strut



04

Stick the rubber at the pointed position for passenger and driver side.
(This is to fix the motion path of cables so they don't get caught any more)

At last, the installation is done

