

# PACKAGE CONTAINS

FOR FORD RANGER WILDTRAK/RAPTOR/ XLT+ 2023



1 x slow down strut  
*(driver side)*

1 x ball bolt





# INSTALLATION INSTRUCTIONS

FOR FORD RANGER WILDTRAK/RAPTOR/ XLT+ 2023

01

**\*\* Installation begin from the Driver Side \*\***

Attach the slow down strut to the pointing area



02

Remove the bolt from the body and replace with ball bolt provided



03

Pull the strut down and push onto the ball stud. (*You will hear the sound "click".*)



04

At last, the installation is done.

