

RV COVER INSTALLATION

Congratulations on purchasing a Aussie Traveller Cover. Aussie Traveller RV (Caravan, Pop-Top and Camper) covers are designed to provide foremost protection against the harsh Australian conditions whilst also protecting against tree sap, pollutants, dust and animal droppings.

The Aussie Traveller range of RV covers provide universal fitment for a range of RV sizes. It is recommended you measure your RV to ensure you have purchased the correct size of cover. The cover may be damaged as a result of improper sizina.



Caravan Cover Measuring Guide



Measure the body of your caravan at the longest point. Do not include the drawbar.

Pop-Top Cover Measuring Guide



Measure the body of your pop-top at

Camper Cover Measuring Guide



Measure the body of your camper at the longest point. Do not include the drawbar. the longest point. Do not include the drawbar.

Note:

Extrusions underneath and around your RV can be sharp and may damage your cover. Before installing the cover, Aussie Traveller suggests you cover all sharp corners with a cloth tape, or similar tape to protect your cover against tearing. Satellite dishes, air conditioners, antennas and awnings can also have sharp edges. Aussie Traveller RV covers are manufactured with reinforced skirting to protect against tearing from sharp corners, but taking a few minutes to protect the corners will keep your Aussie Traveller RV cover useable for years to come.

Fitting

Aussie Traveller RV covers are easy to install and can be fitted in a short time. Zippered side panels provide easy access to the RV plus a water resistant roof section protects against rain. Water resistant, breathable side panels allow the cover to breathe and moisture to evaporate. Eyelets sewn into the hem allows the side panels to be converted into a handy sun awning, plus 2 dual clip nylon straps attached to both the front and the rear of the reinforced skirt ensures the cover is securely fastened for all conditions.







DO NOT ATTEMPT TO FIT IN BAD WEATHER OR HEAVY WINDS.

- Remove the cover from the box and lay on a flat, dry surface at the side of the RV (opposite to the main entry door). Locate the front of the cover (marked FRONT located above the skirt) and place in the direction towards the front of the RV.
- 2. Stretch the cover out and unzip the zippers at both ends of the cover so that you can flip the unzipped size panels onto the roof section so that the sides are completely open.
- 3. When installing the cover for the first time please take note of any fittings or edges on your RV that may damage the cover. Cover with tape or other protective material.
- 4. Using a step ladder, lift the cover over the top of the RV and slowly pull over the roof area. The securing straps may also be used to pull the cover over the RV. Remember to be careful of objects that may damage the cover. If the cover does not slide freely, check that it is not caught on an edge.
- 5. Once the cover is over the roof of the RV, adjust the edges until it is sitting evenly, begin by securing the rear corners under the RV and making your way around to the front to do the same with the front corners.
- 6. When the cover is sitting evenly, zip up sides and secure into place by throwing the long straps (2 located at either side of the axles) underneath the RV and connecting with the short straps. Pull the straps firmly to hold cover in place. Do no over-tighten straps as it may cause undue tension on the seams.
- 7. At the front and rear of the cover are two quick-lock straps. Secure and tighten.

