

# INTELLI-START IS2000 12/24V LITHIUM JUMP STARTER

Imagine a jump starter for professionals that has UNLIMITED JUMPSTARTS. IS2000 Professional Jump Starter is ideal for roadside assist, small trucks, agricultural and mid sized earthmoving equipment

### Features:

- The IS2000 is the world's first 12/24V jump starter that recharges itself via RRT – Rapid Recharge Technology
- Specially designed cranking battery – LiFePO<sub>4</sub> battery technology engineered for high cranking performance and superior safety
- Safest jump starter on the market - advanced 'all-in-one' protection system preventing surges, short-circuits and overheating
- Workshop tough – durable high impact housing with rubber over-moulded body
- No battery operation – can jumpstart vehicle without a starter battery
- Lightweight & Portable – won't break your back!!
- World's best design and construction – nut and bolt termination
- Easy to use – intuitive colour screen indicates Alarms, Battery Status and Vehicle Status
- Premium glass filled nylon clamps
- Premium EVA carry case, L.E.D work light and USB power bank


### Specifications:

<b>Battery Capacity</b>	2 x 3.0Ah at 12.8V, 24,000mAh at 3.2V (76.8Wh)
<b>Battery Chemistry</b>	Lithium Iron Phosphate (LiFePO <sub>4</sub> )
<b>Battery Cycles</b>	2000 battery cycles (battery lifespan)
<b>Clamp Power</b>	12V 750A / 24V 500A Maximum current available at the clamps
<b>Application</b>	Professional
<b>Types of Vehicle</b>	Starts large 12V & 24V vehicles up to 8.0L petrol & 7.0L diesel
<b>RECHARGING</b>	
<b>Via</b>	12V USB-C lead (12V to USB-A adaptor) 240V Charging Dock (15V 1A AC adaptor)
<b>Source</b>	RRT Via vehicle starting battery
<b>JUMP STARTER</b>	
<b>Weight</b>	2.6kg
<b>IP Rating</b>	IP55

P/NO.	QTY	DESCRIPTION
IS2000	1	12/24V 2000A Jump Starter



STARTS 12V VEHICLES UP TO **8L 6L** PETROL DIESEL  
STARTS 24V VEHICLES UP TO **7L** DIESEL



IS2000

### Rapid Recharge Technology (RRT)

Projecta Intelli-Start are the only jump starters in the world that recharge themselves directly from the vehicle they just started. Simply leave the clamps connected for 40 seconds and the jump starter will be fully recharged meaning it is always ready for the next use.

### APPLICATION GUIDE

