




everstay folding recliner

user manual





Installation instructions

Tools required none

Estimated time 3-5 minutes



1. Expand steps

First, extend points A & B, then extend points B & C, and adjust the recliner to a stretched position.





2. Lock adjustment

1. Push down the back lock, step on the footrest lock, and secure the recliner in the extended position.
2. Release the armrest lock, push back to adjust to a comfortable angle, then lock it. Adjustment complete.



3. Folding step guide

1. Set the recliner to a 90° position.
2. Unlock the back and footrest, fold diagonally to complete.



Usage guidelines

1. Ensure the backrest is fully extended and locked before use.
2. Always use the chair on stable and level ground.
3. Avoid placing the chair near open flames or in extreme heat conditions.

Safety warnings

General warnings

Maximum load 150kg

Fire hazard Keep away from open flames or high heat sources.

Child safety Small parts may pose a choking hazard for children under 3 years old.

Stability Ensure all components are securely locked before use.

Maintenance & cleaning

1. Clean the recliner with a damp cloth. Avoid abrasive or chemical cleaners.
2. Store in a cool, dry place when not in use.
3. Regularly inspect screws and connections to ensure they remain tight.

Environmental & recycling instructions

1. Frame is recyclable, dispose of it per local regulations.
2. Do not discard this product as household waste; follow your region's recycling guidelines.
3. Use eco-friendly cleaning solutions to minimise environmental impact.

Warranty

Warranty period 2 years from the date of purchase.

Coverage Material and manufacturing defects under normal usage conditions.

Exclusions Damage caused by misuse, improper storage, or unauthorised modifications.

Key features

Material	High-strength carbon steel frame. Textilene fabric
Maximum loading capacity	150kg
Dimensions (Opened)	L118 x W66 x H85cm
Dimensions (Folded)	111 x 23 x 21cm
Ideal for	Sunbathing, relaxing, reading, camping

Package contents

1 x Recliner 1 x Carry bag 1 x User manual