

Make / Model MITSUBISHI 380/SEDAN

Other

Year 10/05 - ON

Part number T2C488

Maximum towing capacity 1600 kg

Maximum ball load 160 kg

Bar weight 17 kg

Fit with wiring harness part No.

Fitting Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS FROM TOWBAR TAKING NOTE OF LOCATIONS.
 - 1.1. UNDO EXHAUST FROM REAR HANGERS.REMOVE BOLTS FOR HEAT SHIELD TO GAIN ACCESS TO EXISTING CAPTIVE NUTS IN SUBFRAME.
 - 1.2. REMOVE SHIPPING HOOKS IF INSTALLED. [DISCARD]
 - 1.3. REMOVE BOTTOM BUMPER SUPPORTS.
2. FIT TOWBAR ONTO VEHICLE USING M10 BOLTS AND WASHERS SUPPLIED INTO EXISTING CAPTIVE NUTS.
 - 2.1. TIGHTEN ALL BOLTS TO SPECIFIC RATINGS.
 - 2.2. REFIT HEAT SHIELD / REFIT EXHAUST / REFIT BUMPER SUPPORTS.
3. FIT BALL MOUNT USING M16 BOLTS AND WASHERS SUPPLIED AND TIGHTEN.
 - 3.1. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

Torque table for bolt tightening