

INSTALLATION OF 'OUTBACK' ROOF CONSOLE

100 SERIES LANDCRUISER - GXL 04/98 – 07/02 & STANDARD 04/98 – 10/07

PART NO. RC10098

Failure to connect coloured wiring correctly and tape up all connections as described in following instructions will result in an electrical short and void console warranty.

For this installation you will need a **long** Phillips screwdriver, **short** Phillips screw driver, 'Loc-Tite' and insulation tape.


VEHICLE PREPARATION:

Swing Sun Visors around to side and lay flat to roof for ease of installation.

Remove rear view mirror, retain screws and plastic cover.


Switch interior light to off position, remove from roof, disconnect wiring and put aside, retain screws for fitting.

Rear Fixing Plate installation: Using a **hand held** Phillips screw driver fasten Rear Fixing Plate to four interior light screw holes. Use original interior light screws and fasten plate ensuring captive nuts point down and face **front** of vehicle and interior light plug protrudes out side of plate. Fasten **yellow** earth wire supplied to one of these screws.



INSTALLATION PREPARATION:

Connect wiring extension supplied to console wiring loom; connect **red** to **red**, **white** to **white** and **yellow** to **yellow**. Tape up connections.



Fasten Front Mounting Bracket supplied to **inside** front of Roof Console using two (2) 6mm x 16mm **black** Phillips round head bolts supplied.



Comfortable work position: Slide seats all way back, if right handed, sit in passenger seat; if left handed, sit in driver seat.

Use 'Blu-Tack' provided to adhere one of the 6mm x 30mm round head bolts supplied to **long** Phillips screw driver, put a small amount of 'Loc-Tite' on thread and store in a convenient location, eg: on seat of vehicle or in/on centre console.

CONSOLE INSTALLATION:

Stand console upright on front seat and plug console wiring into interior light plug of vehicle. Plug **white** wire on console into **green/white** wire of interior light plug, **red** into **red** wire and **yellow** into **yellow** earth wire fastened to Rear Fixing Plate. Check that console lights work independently once doors are shut and timer switches off then tape up to ensure wires do not become disconnected.



There is an on/off switch located in front of front lights, when off it acts as a kill switch and no lights will work; when on lights work independently as map/interior lights when doors are shut and timer switches off; when doors are opened lights will work as door/interior lights.

Position console in centre of vehicle then look up under and into rear mounting hole; line up captive nuts in Rear Fixing Plate with slotted fastening holes, tuck wiring loom out of way so as not jam between console body and rear mounting plate. Use the 6mm x 30mm round head Phillips bolt 'Blu-Tacked' to your **long** Phillips screw driver and **loosely** fasten rear of console up to one of captive nuts in Rear Fixing Plate.

Line Front Mounting Bracket holes up with rear view mirror screw holes and push front of console **firmly** up against roof. Screw rear view mirror back into place through Front Mounting Bracket using original screws and replace plastic cover.

'Blu-Tack' other 6mm x 30mm round head bolt to screwdriver, apply 'Loc-Tite' to thread and fasten into remaining captive nut in Rear Fixing Plate. Tighten both rear bolts. **Note:** *Only tighten bolts up firm so as console is held to roof, **do not** keep on tightening so as to bend rear mounting plate downward; do rear bolts up with equal tension.*

Open Locker Box and remove Microphone Cable Holder and Rear Mounting Hole Cover from inside; fasten Hole Cover in place using screws supplied. Fasten Microphone Cable Holder in place as per radio installation instructions.

Fit Kit: RC10098

- One (1) Front Mounting Bracket
- One (1) Rear Fixing Plate (colour marked)
- One (1) Wiring extension
- One (1) Yellow earth wire
- Two (2) 6mm x 16mm **black** Phillips round head bolts
- Two (2) 6mm x 30mm Phillips round head bolts
- One (1) Small piece of 'Blu-Tack'
- Three (3) x 100mm Sticky back foam pieces

RADIO INSTALLATION

Radio Insert Installation: for smaller size radios

PLEASE NOTE: Radio Inserts NOT INCLUDED.

Decorative side of insert faces outwards and snaps out over bottom of tray surround.

To install insert, squeeze top and bottom together; push/bend sides and squeeze into tray surround from inside to outside until bottom lip on decorative side of insert snaps/pops out over bottom of tray surround, prize with fingers to ensure bottom lip of insert is in place over tray surround as described. **Do not** scratch or mark insert or surround by prising/levering with tools; use hands/fingers only.



Radio Installation:

Place protective cover on work bench to avoid scratching console. Place console on protective cover and using a sharp knife cut a 30mm x 100mm section out of storage tray 25mm in from where rear of radio will be when installed. Use a small amount of methylated spirits on a clean cloth to clean exposed part of console and bottom rear of radio.



Peel one side of protective backing from foam strip supplied; apply pressure with palm of hand to adhere foam to exposed part of console. Peel backing off other side of foam strip and add one or more strips of foam to suit different size radios (see chart below). This will keep radio level with bottom of surround.



Insert radio on an angle until radio protrudes 15mm out over bottom of tray surround or insert and straighten; lay flat onto sticky back foam and apply firm pressure to top of radio with palm of hand for 30 seconds to ensure good adhesion.



Sticky back foam chart:

- One (1) strip- standard size radios
- Two (2) strips- Icom and Uniden
- Three (3) strips- GME Electrophone

Microphone and Microphone Cable Holder installation:

Install in a position that suits best, depending on vehicle and Radio model. Ensure microphone or microphone cable and holder does not foul on sun visor when pulled down.



Microphone clip on slight angle



Left hand cable outlet radios



Microphone clip on acute angle